

*business*phone

...it's your business



*User's Guide*

BUSINESSPHONE 250  
BUSINESSPHONE 50

Basic Telephone

BUSINESSPHONE 250 / BUSINESSPHONE 50  
BASIC TELEPHONE, DIALOG 3210

USER'S GUIDE

EN/LZTBS 102 193 R2B

Copyright © 1999. Ericsson Austria AG. All rights reserved.

This document contains proprietary information which is protected by copyright. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, or translated into another language, without prior written consent of Ericsson Austria AG, Vienna, Austria.

The information in this document is subject to alteration without prior notice.

ERICSSON MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Ericsson shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Ericsson Austria AG  
BusinessGroup BusinessPhone  
Pottendorfer Strasse 25-27  
A-1121 Vienna, Austria  
Telephone: +43-1-81 100-0  
Telefax: +43-1-81 100-5437

Welcome to the User's Guide for the Basic phone in the BusinessPhone 250 / BusinessPhone 50 system from Ericsson.

It is a state-of-the-art business communications system. Its alliance of features and facilities effectively improves communications for virtually any kind of organization.

To take full advantage of these advanced features and facilities there is a line of phones, designed for ease of use in every situation.

Your phone is equipped with programmable keys for single-key access to frequently used functions and numbers.

The User's Guide describes the facilities of the BusinessPhone system and the Basic phone with a factory defaults programming. There may be some differences in the way your phone is programmed. Please consult your system administrator if you need further information.


Function descriptions that do not include speaking in the handset, are described as off-hook, if nothing else is stated. Instead of pressing the "Clear-key", you can always replace the handset.

*Note: Dialog 3210 is a system telephone, i.e. it can only be used for an Ericsson private branch exchange that supports this type of telephone.*

### Table of Contents

	page
Description .....	5
Incoming calls .....	7
Outgoing calls .....	8
During calls .....	10
Call forwarding .....	15
Information .....	18
Internal messages .....	22
Mailbox system .....	24
Abbreviated numbers .....	28
Group facilities .....	31
Other useful facilities .....	36
Security .....	42
Least Cost Routing .....	44
Optional equipment .....	45
Programming .....	48
Visible signals .....	51
Audible adjustments .....	52
Tones and signals .....	54
Glossary .....	55
Installation .....	57
Useful hints .....	59
Index .....	60
Quick Reference guide .....	63

DESCRIPTION



(continued)

### DESCRIPTION (continued)

- 1 Message / Conference**
  - a. To send and receive messages. See section "Internal messages".
  - b. To establish a telephone conference. See section "During calls".
- 2 Programmable key / Headset key**
  - a. Storing numbers and program functions.
  - b. The headset function is only available with option unit (DBY 410 02) installed. The headset key is programmed by the system administrator. See section "Optional equipment".
- 3 Programmable keys**

Storing numbers and program functions.  
See section "Programming".
- 4 Inquiry**

To make an inquiry to an internal or external party.  
See section "During calls".
- 5 Line**

Line key for in and outgoing calls.
- 6 Volume control**

To adjust the volume. See section "Audible adjustments".
- 7 Mute**

To switch the microphone on or off.  
See section "During calls".
- 8 Loudspeaker on/off**

To switch the loudspeaker on or off.  
See section "During calls".
- 9 Clear**

To disconnect calls.
- 10 Loudspeaker**
- 11 Handset with hearing aid function**

*Please note: The handset may retain small metal objects in the earcap region.*

## INCOMING CALLS

### GENERAL

A ringing signal and a flashing lamp indicates an incoming call.

### ANSWER CALLS



#### Lift the handset

#### On another extension



You can answer a call to a phone in another room:

#### Lift the handset and call the ringing extension

You receive busy tone.



#### Press

#### A second call is waiting

A muted ringing signal will inform you, during a conversation, that a second call is waiting on your phone.

To answer the second call:



#### Press to finish the ongoing call

The new call will be signalled on your phone.



#### Press to receive the new call

### OUTGOING CALLS GENERAL

Sometimes you make a call but the person is not available. These functions will help you in your attempts to establish contact with the called party.

### MAKE CALLS

How to make internal and external calls.



**Lift the handset and dial either:**




**An extension number to make an internal call,**  
**or**



**The digit(s) for external calls and external number**

*Note: Which digit to press for external calls, depends on the configuration of the system.*



**To end the call**

*Note: You can make your calls faster, using common abbreviated numbers and by programming your own abbreviated numbers.*

### LAST EXTERNAL NUMBER REDIAL

When you initiate an external call the system automatically stores all the dialled digits, irrespective of whether the call was successful or not.



**Lift the handset and press to redial the last dialled external number**

### SAVE EXTERNAL NUMBER

When you make an external call, you can save the number in order to redial it easily. Previously saved number is erased. Before you finish the call:



**Press to save the dialled number (pre-programmed)**

### Redial number



**Press to redial the saved number (pre-programmed)**



## AUTOMATIC CALL-BACK

You call an extension and receive busy tone or get no answer.

5

### Press

Verification tone.



### Press or replace the handset to finish the procedure

You are called back if the extension finishes the ongoing call or the next time the extension finishes a new call. You have to answer within eight seconds otherwise the call-back service is cancelled.



### Lift the handset when you are called back

## BUSY EXTENSION

You call an extension and receive busy tone.

### Camp-on

You can notify a busy extension of your call by a muted ringing call (if this function is allowed).

4

### Press to camp on

Keep the handset off hook. When the called extension replaces the handset, it will be called automatically.

*Note: If you receive the busy tone again, the desired extension does not allow camp-on.*

### Intrusion

You can intrude on an ongoing call on a busy extension (if this function is allowed).

8

### Press to intrude

Intrusion tone is heard and a three-party call is established. When the called extension replaces the handset and you keep off hook, the called extension will be recalled automatically.

*Note: If you still hear the busy tone, then your extension does not have the authority to intrude or the desired extension is protected against intrusion.*

### DURING CALLS GENERAL

The BusinessPhone 250 / BusinessPhone 50 system allows you to handle calls in many different ways. You can monitor calls, mute the microphones, make an inquiry, transfer the call, create a conference or put the call on hold to perform other tasks.

---

### MONITORING

You have an ongoing conversation via the handset.



#### **Press to switch the loudspeaker on**

The loudspeaker monitors the call.

*Note: When the loudspeaker is on, the microphone is automatically switched off in the handset. You can adjust the volume, see section "Audible adjustments".*

---

### From monitoring to handset



#### **Press to switch the loudspeaker off**

Continue your conversation via the handset.

---

### MUTE

You can turn off the microphone of the handset. Then the caller will not be able to hear the conversation in your room.




#### **Press to switch the microphone on or off**

The lamp lights, if the microphone is turned off.

**INQUIRY**

During an ongoing conversation you like to make an inquiry to an internal or external party.

**Inquiry** 

**Press**

The first call is put on hold (the lamp flashes slowly).

**Call the third party**

When the third party answers you can switch between the calls, create a conference and end one of the calls.

**End inquiry****Press to end the inquiry call**

The second call is disconnected.

**Line** 

**Press to retake the first call**

Now you are connected to the first party.

**REFER BACK**

You have an ongoing conversation and want to refer back to the parked call. The lamp flashes at the parked call.

**Line** 

**Press to park the second call**

First call is connected.

**Inquiry** 

**Press to park the first call**

Second call is connected.

**Press to end the ongoing call**

### TRANSFER

You have an ongoing internal or external conversation and you want to transfer an ongoing call.

**Inquiry** 

**Press**



#### **Call the third party**

You can transfer the call before answer or wait for answer

*Note: Make sure, that you are connected to the desired party. Please read the notes and warnings in section "Useful hints".*



#### **Replace the handset**

The call is transferred. External calls might only be transferred with the Transfer-key, if this state of connection is allowed by the system-programming.

---

### **Transfer to a busy extension**

You can even transfer calls to busy extensions. The other party will hear a muted signal (camp-on), and the call will be extended, as soon as the ongoing call is terminated (if camp-on is allowed).

---

### **Call-back**

You are called back, if you have transferred an external call and the other extension has not answered the call within a certain time. Your telephone will ring again.

## CONFERENCE

You have an ongoing conversation and you want to establish a telephone conference.

**Inquiry** 

**Press**



**Call the third party**

**Message/  
Conference**



**Press**

Now you have established a three party conference. To mark the conference, all conference members will hear a periodical conference tone.

### **Repeat the procedure to include other persons to the conference**

In this way, you can include up to six parties in a conversation. How many of them can be external callers depends on the programming of the system.

## INDIVIDUAL HOLD

You have an ongoing conversation, i.e. the "Line"-key is lit. Now you want to park the ongoing call for a short while.

**Line** 

**Press the line key**

The lamp flashes slowly.

**Line** 

**Press again to retake the parked call**

*Note: This is also valid for the "inquiry"-key.*

### COMMON HOLD

*Hold* 

#### **Press (pre-programmed)**

The line key lamp flashes slowly. The call can be picked up on any extension within one minute, or else it will recall on the holding extension.

*Line* 

#### **Press to pick up on own extension**

**or**

Pick up on another extension:



#### **Call the extension that put the call on hold**



**Press**

## CALL FORWARDING GENERAL

When you are not available to take calls or decide to answer your calls on another extension, it is useful to forward your calls to an alternate answering position.

If you urgently need to talk to someone who has forwarded his calls, the system is also equipped with a bypass function.

*Note: You can still make calls as usual.*

---

### Diversion on no reply

If you are not available to answer incoming calls (internal or external), your system administrator can program your extension to automatically divert calls to a programmed diversion address (default time: 15 seconds).

---

### Diversion on busy

If your extension is busy and you receive an incoming call (internal or external), your system administrator can program your extension to automatically divert the call to a programmed diversion address.

---

## FIXED DIVERSION

This function directs your calls to a pre-programmed answering position (e.g. secretary).

---

### Activate fixed diversion



**Press to activate diversion**



**Press**

---

### Cancel diversion



**Dial to deactivate fixed diversion**



**Press**

### INDIVIDUAL DIVERSION

This feature gives you the possibility to divert your calls to any directory number, e.g. to a colleague's extension or a common abbreviated number (e. g. your car telephone). Depending on the programming, external calls can also be diverted to an external diversion address (or otherwise to the operator).

#### Activate individual diversion



**Dial**



**Enter the new diversion address**



**Press to active the individual diversion**

Special dial tone.



**Press to finish the procedure**

You can make outgoing calls as usual.

A special dial tone reminds you that "Call forwarding" is active.

#### Cancel diversion



**Dial**



**Press**



## FOLLOW ME

To activate Follow me, "Individual Diversion" must be active on your telephone.

### Activate Follow me



**Dial**



**Dial your number and press**



**Dial the new number and press**

Special dial tone.



**Press to finish the procedure**

### Cancel Follow me

Follow me and individual diversion can also be cancelled from the answering position.



**Dial**



**Dial your number and press**

Dial tone.



**Press to finish the procedure**

## BYPASS CALL FORWARDING

Bypass call forwarding makes it possible to call a specific extension, even if call forwarding is activated on this extension.



**Lift the handset**



**Press**



**Enter extension number**



**Press**

You will be connected to the specified extension, no matter if it has activated fixed diversion, individual diversion or follow me.

### INFORMATION GENERAL

If you are not in the office for a certain period of time (e.g. meeting, vacation, lunch, illness), this feature allows you to inform your callers why you are absent. External callers will be routed to the operator who also has access to your absent info.

*Note: This will not work, if the voice information is used as a personal greeting for your individual mailbox.*

You can inform your callers with:

#### **1) Pre-defined texts**

Enter the reason for your absence and the date and time of your return.

#### **2) Voice information**

Record a voice message and name your absent information.

---

### ENTER INFORMATION

To store text or voice information.



**Press to enter the information mode**

**Select "Pre-defined text" or "Voice information"**

Pre-defined texts

From the table below:



Enter "Code" and



Enter "Completing info"

	Code	Completing info
Time of return	1	hour (00-23) minute (00-59)
Date of return	2	month (01-12) day (01-31)
Lunch	3	back at, hour minute
Meeting	4	back at, hour minute
Vacation	5	back, month day
Illness	6	back, month day



Press to enter the information




Press to finish the procedure

Internal callers receive the information on the display (or as spoken information to callers without display phone).

Pre-defined texts

Example:



*Vacation, back June 27*

If you do not know the time of return, just press #.  
Information active. Internal callers receive the information on the display (or as spoken information to callers without display phone). External callers will be routed to the operator who also has access to your absent info.

(continued)

### ENTER INFORMATION (continued)

#### Voice information



**Press to enter information mode**



**Press and speak**



**Press to play-back and listen to your recording**



**Press and speak to re-record**



**Press to send**

Information active.



**Press to finish the procedure**

Internal callers will hear the information via the handset or the loudspeaker. External callers will be routed to the operator who also has access to your absent info.

***Note:** You can dial your own extension number if you want to check your information.*

## ERASE INFORMATION, SAVE INFORMATION



**Press to erase info**

**or**



**Press to deactivate and save for later use**

Information is passive.



**Press to finish the procedure**

---

## Use saved information

When the information is switched off:



**Press to activate saved info**

Information is active.



**Press to finish the procedure**

## INTERNAL MESSAGES

### GENERAL

When you call an internal number and receive busy tone or get no answer, you can send a message to that extension.

Two possibilities exist:

#### 1) Call-back message

#### 2) Voice message (see also "Mailbox System")

Your incoming messages are indicated on your telephone by the rapidly flashing "Message/Conference"-key.

### SEND MESSAGE

You can send a message when you call an extension and receive busy tone or get no answer.

#### Call-back

Send a "call me" message.

**Message/  
Conference**



**Press**



**Press to send**

#### Voice

**Message/  
Conference**



**Press**



**Press and speak a voice message**



**Press to play-back and listen to your recording**



**Press and speak to re-record**



**Press to send**

**RECEIVE MESSAGE**

The message lamp flashes rapidly.

**Message/  
Conference**

**Press to receive a message**

"Call me" messages will call the sender automatically.

Voice messages will be heard via the speaker or the handset.

The message lamp is flashing rapidly during the procedure and will extinguish after the last message.

*Note: Depending on the configuration, you might be asked for your personal code before you can retrieve your messages. See section "Security".*

**Press to finish the procedure**

## MAILBOX SYSTEM GENERAL

While you are away from the office, callers can leave messages in your individual or in a common mailbox. You are also able to record your personal greeting.

The difference between your individual mailbox and a common one is that a common mailbox can be used for more than one user.

## INDIVIDUAL MAILBOX SYSTEM

Callers are able to leave messages in your individual mailbox.

### Activate

Divert your extension to the mailbox system.



**Press**



**Dial the number to the mailbox system**

Ask the system administrator for your defined mailbox number.



**Press**



**Press to finish the procedure**

When the diversion to your mailbox is activated, the Diversion lamp shows steady light.

### Deactivate



**Press**



**Press to finish the procedure**



## Retrieve messages - internally



When a new message is received, the message lamp flashes rapidly.

### Lift the handset

**Message/  
Conference**



### Press to retrieve a message

Further procedure, see section "Internal messages - Receive message".

## Retrieve messages - externally



To retrieve your messages from an external position:

### Lift the handset



### Dial your company's telephone number



### Dial the number to the mailbox system

During the procedure you will be asked for your extension number and your personal code.

## COMMON MAILBOX SYSTEM

Callers are able to leave messages in the common mailbox.

### Activate



Divert your extension to the mailbox system.

**Press**

### Dial the common mailbox number

Please ask the system administrator for your defined mailbox number.

**Press**

### Press to finish the procedure

When the diversion to your mailbox is activated, the Diversion lamp shows steady light.

### Deactivate



**Press**

### Press to finish the procedure

## Retrieve messages - internally

During the procedure you will be asked for your extension number and your personal code. Which personal code is programmed and how to change it, see section "Security".



**Lift the handset**

*Common mailbox*

### Press the common mailbox key (pre-programmed)

During the procedure you will be asked for your extension number and your personal code. See section "Security".

## Retrieve messages - externally



To retrieve your messages from an external position:

### Lift the handset

### Dial your company's telephone number

### Dial the common mailbox number

During the procedure you will be asked for your extension number and your personal code.

## PERSONAL GREETING

When you have diverted your extension to the individual- or common mailbox system, you can leave a personal greeting to the caller.

### 1) Enter the information

Pre-defined texts or voice information. How to enter information, see section "Enter information".

### 2) Activate diversion to the mailbox system

How to activate, see sections "Individual mailbox system" or "Common mailbox system".

### ABBREVIATED NUMBERS GENERAL

By using abbreviated numbers, you can make calls simply by pressing a few keys.

Frequently used external numbers are stored as "common abbreviated numbers" in the exchange.

10 "individual abbreviated numbers" (your personal most frequently used external numbers) can be stored and used on the keys "\*\*0" to "\*\*9".

---

### COMMON ABBREVIATED NUMBERS

External numbers are stored centrally in your BusinessPhone system. Common abbreviated numbers have a maximum of 4 digits and can be dialled from every extension that has the authority to do so.



**Lift the handset**



**Dial the common abbreviated number**

Please refer to your telephone directory.


---

### DIAL-BY-NAME

You can program and activate directory numbers (extensions and common abbreviated numbers) on the programmable keys. If you have programmed a number on a programmable key, you just have to press this key to call the desired person.



**Lift the handset**

*Michael P.* 

**Press to make a call (pre-programmed)**

---

## Program dial-by-name

How to program an internal directory number on a programmable key.



**Enter programming mode**



**Press a programmable key**



**Press**



**Press the programmable key again**



**Dial the number**

You can use any directory number, e.g. a common abbreviated number or a colleague's extension number.



**Press the programmable key again**



**Press to finish the procedure**

## INDIVIDUAL ABBREVIATED NUMBERS

You can program and activate your most frequently used external numbers on the keys "\*\*0" to "\*\*9".



**Lift the handset and press**



**Dial the abbreviated number**

A number between 0 and 9.

(continued)

## INDIVIDUAL ABBREVIATED NUMBERS (continued)

### Program individual abbreviated number

How to program external numbers on the keys 0 to 9.



**Enter programming mode**



**Select an abbreviated number between 0 and 9 and press**



**Dial the external number and press**

The number can consist of up to 24 digits. Press \* if you have to wait for dial tone.



**Press to finish programming**

---

### Cancel one specific individual abbreviated number



**Press**



**Enter an abbreviated number between 0 and 9**



**Press**

---

### Cancel all individual abbreviated numbers



**Press**

Conformation tone.

## GROUP FACILITIES

### GENERAL

When you are working together in a team the following group facilities can be very useful. You can page your colleagues, give them telephone attendance or pick up their incoming calls.

### LOUDSPEAKER PAGING

You can page all extensions in a group and give a voice message.



#### Lift the handset



#### Press (pre-programmed)

All extensions in a group are called.



#### Press again and hold the key (pre-programmed)

Give the voice message and then release the key.

Now you can wait for answer, or terminate. If you do not get an answer within 30 seconds, the paging function will be terminated automatically.

### Answer paging

A short signal and a flashing "Paging"-key will inform you when a loudspeaker paging is received.



#### Lift the handset



#### Press (pre-programmed)

An internal call is established with the paging party.

### KEY SYSTEM

With this function, all (or selected) external lines are represented by pre-programmed keys on all phones. For each external line, a function key has to be programmed. Which means that you are able to monitor the state of traffic for every programmed external line (e. g. free, busy). You can also establish an external call by pressing the external line key.

#### Answer an external call



*External line*



To answer an external call, just press the flashing key. (Depending on the programming of the system, an incoming external call will be announced with a flashing line-key and a ringing signal).

#### Lift the handset

#### Press (pre-programmed)

Speech connection with the caller.

#### Make an external call



*External line*



To initiate an external call, just press the external line key. The external line will be seized automatically.

#### Lift the handset

#### Press a free line-key (pre-programmed)



#### Dial the desired number


If you make external calls in this way, you do not have to dial the digit(s) for external calls first.




## SUPERVISION/ TELEPHONE ATTENDANCE

A function-key can also be programmed for supervision and handling calls for a group of extensions. If a supervision/attendance-key is programmed on your telephone, you are able to call the other group-members or answer incoming calls for the group by pressing the key and monitor the activity of other extensions (free, busy, called).

### Traffic situation

Michael 

**Ongoing conversation (lamp is on)**

Michael 

**Free extension (lamp is off)**

Michael 

**The extension is called (flashing lamp)**

### Pick-up calls for the group

Your colleague's extension is indicated on your phone by a pre-programmed key.



**Lift the handset**

Michael 

**Press to answer the calls directly  
(pre-programmed)**

A flashing lamp beside the key indicates an incoming call.

### Call a group-member



**Lift the handset**

Michael 

**Press to make the calls directly  
(pre-programmed)**

*Note: If the key is flashing, you will automatically pick-up your colleague's ongoing call.*

### GROUP HUNTING

Your telephone can be included in a hunt group, where all members are represented with one common directory number.

Incoming calls to the hunt group, follow the same procedure as calls to normal directory numbers, then the call is directed to free extensions in the group. The hunt order within the group can be changed to suit your needs.

Only one group hunting call can be handled at a time, i.e. a second incoming group hunting call cannot be presented on your other line. However you can still receive group hunting calls to your extension number, if you are busy with a normal call

*Note: If all members in a hunt group are busy, the call-back or intrusion functions are not available, however the camp-on function can still be used.*

16 hunt groups can be programmed, each containing 1 to 20 members. A hunt group member can be either an extension number, an operator console or a fictive number.

To answer incoming group hunting calls:



**Lift the handset**

---

### GROUP CALL PICK UP

In a Pick up group, any member can answer any individual call to group members. You answer a call to the group by dialling a special answering number. Please ask your system administrator for the configured number.



**Lift the handset**



**Dial the group call pick up code**

---

## COMMON BELL



The common bell facility allows all extensions of the system (operator included) to pick up the call from an extension that has been predefined as a common bell extension.

### Dial the common bell pick up code

Please ask your system administrator for the common bell pick up code.

### Lift the handset

You will immediately be connected with the calling party.

If two or more extensions simultaneously attempt to answer a call from the common bell extension, only the first extension will pick it up. The other extensions will receive the "number unobtainable" tone.

This will also happen if you dial the common bell pick up code and there are no calls waiting at the common bell extension.

***Note:** You can also program the common bell code on a function key.*

### OTHER USEFUL FACILITIES GENERAL

By using these facilities your productivity will be increased, e.g. you can set reminders for important meetings, place the costs for external calls on separate accounts, listen to music via the loudspeaker and much more...

### REMINDER

The phone can be set to remind you at any time within the next 24 hours (multiple settings are allowed).



**Press**



#### **Dial reminder time and press**

(00-23) hour + (00-59) minute. Delete the at last entered digit with the "minus" -key.

*Note: If you receive busy tone, your extension does not have the authority to set a reminder.*



#### **Press to finish programming**

When the reminder time is reached, your phone rings with recall signal.

### Cancel reminder



**Press to cancel all settings**



**Press to finish the procedure**

**ACCOUNT NUMBER**

You can place the costs for external calls on a selected account number (up to 15 digits).

---

**Enter account number  
before the call**


**Lift the handset**



**Dial**



**Enter account number and press**  
Internal dial tone. Make the external call.

---

**Enter account number  
during the call**

*Account number* 

**Press (pre-programmed)**



**Enter account number and press**

### BACKGROUND MUSIC

You can listen to background music over the loudspeaker on your phone by pressing a pre-programmed Music key, or by entering the number for the music channel. Please ask your system administrator for the configured number.

*Background music* 

#### **Press to activate the music (pre-programmed)**

The music automatically switches off when you make or receive calls and switches on again when the call is finished.



#### **Press to cancel the music**

*Note: You can adjust the volume, see section "Audible adjustments".*

---

### INTERCOM LINE

A two-way direct call function between two extensions, for instance in executive-secretary communication.



#### **Lift the handset**

*Intercom to Secretary* 

#### **Press to establish an intercom call (pre-programmed)**



#### **Press to cancel the intercom call**

---

### NIGHT SWITCHING

If you want this facility, please ask your system administrator. This function is used for directing all incoming calls to one extension (answering position), for example when the office is closed.

*Night* 

#### **Press to activate or deactivate (pre-programmed)**


When the lamp lights, night switch is active. When the lights extinguishes, night switch is passive.

## TANDEM CONFIGURATION

The tandem configuration is a unit, consisting of two telephones using the same directory number. One of the telephones is defined as the "master" and the other one as the "slave".

This function enhances the communication for users that, for example, have a wired phone on their desk (the "master telephone") and need to be mobile within their company's building with their own portable (the "slave telephone"). Basically the tandem configuration works as follows:

### To activate the tandem configuration

*Slave log on/off* 



**Press (pre-programmed)**

or

**Press to log on the slave telephone**

For incoming calls:

- Both telephones are treated as 1 single extension.

For outgoing calls:

- Both telephones are treated as 2 separate extensions.

### To deactivate the tandem configuration

*Slave log on/off* 



**Press (pre-programmed)**

or

**Press to log off the slave telephone**

For incoming calls:

- The "Slave" telephone cannot be called and the "Master" telephone works as a normal "stand-alone" telephone.

For outgoing calls:

- Both telephones are treated as 2 separate extensions.

**(continued)**

### TANDEM CONFIGURATION (continued)

#### Transferring a call between the members of a tandem unit

*Inquiry*



**Press and dial own directory number**

*Transfer*



**Press (pre-programmed)**

**or**



**Go on-hook**

### DIRECT INWARD SYSTEM ACCESS (DISA)

If you are working externally and you have the need to make business calls, call your company and use the company PBX to make an external call to the desired party.

You just pay the costs for the phone call to your company.

The other costs will automatically be placed on your extension number or on a special project.



**Lift the handset and dial the public number of  
your company**



**followed by the DISA number**

Please ask the system administrator for the defined DISA number.



**Dial the external number**

***Note:** During the procedure you will be prompted for your personal code. Which code to use and how to change it, see section "Select Personal Code". See last page for a card to remember these specific numbers.*



## AUTOMATED ATTENDANT

The Automated Attendant facility sends voice instructions to external and internal callers, informing them of all possible options they can choose. Voice instructions lead the callers step by step to the desired destination.



### Lift the handset



### Dial the Automated Attendant directory number

Please ask your system administrator for the Automated Attendant directory number.

## DOORPHONE

The doorphone is used to monitor the admission to your company, i.e you can open the doorlock from your phone.

### Answering door-phone calls



### Lift the handset

You will be in speech connection with the calling party.

### Opening of the doorlock

After you have answered the doorphone, you can open the door making an inquiry to the door-opener's directory number.



### Press



### Dial the door-opener's directory number

Please ask your system administrator for the number.

*Note: You can also program the door-opener's directory number as a common abbreviated number or a function key.*

## SECURITY GENERAL

You can block your extension in order to prevent unauthorized use of your telephone, e.g if your external calls are placed on a specific account number.

### BLOCK EXTENSION



**Dial to block your extension**

Verification tone.



**Press to finish the procedure**

### Un-block extension



**Dial**



**Dial your personal code and press to re-open**

Verification tone. Your extension is open for use.



**Press to finish the procedure**

## SELECT PERSONAL CODE

You can use your four-digit code for blocking your phone from unauthorized use, or for making external calls from any blocked extension.



**Dial to select a new code**



**Dial your present code and press**

The default personal code is "0000".



**Dial your new code and press**

Verification tone.



**Press to finish the procedure**

## BYPASS BLOCKED EXTENSION

In order to make a call, you can temporarily bypass a blocked extension.

### Bypass own extension



**Lift the handset**



**Dial**



**Dial your personal code and press**

Dial tone. You can make one call from your extension.

### Bypass another extension



**Lift the handset**



**Dial**



**Dial your personal code and press**



**Dial your extension number and press**

Dial tone. You can make one call from the blocked extension.

## LEAST COST ROUTING GENERAL

Least Cost Routing (LCR) automatically selects the cheapest way to establish the connection to the desired external number. Please ask your system administrator if this function is installed in your system.

## LEAST COST ROUTING

If the extension has been configured to use LCR, each external call will be analysed and the cheapest way will be selected.

### Use least cost routing



**Lift the handset**



**Dial the digit(s) for external calls and external number**

The usual way of making an outgoing external call.

### Calling least cost routing

If LCR has been installed in your system, but your extension is not configured to use it automatically, you also have the opportunity to get the cheapest connection by dialling the LCR code before you dial an external number.



**Lift the handset**



**Dial the LCR code**

Please ask your system administrator for the LCR code.



**Dial the digit(s) for external calls and external number**

*Note: You can also program the LCR code on a function key.*

## OPTIONAL EQUIPMENT GENERAL

This chapter describes optional features that can be used together with your BusinessPhone telephone.

## OPTION UNIT

The Option unit DBY 410 02 is an optional accessory, to be installed on the bottom of your telephone set. The following devices can be installed via the Option unit:

- Tape recorder
- Extra bell or busy indication outside your door
- Enhanced headset functionality or a conference unit  
*Note: Regarding the headset functions see previous section.*
- PC sound card
- Second handset

*Note: For people with impaired hearing the Option unit offers the possibility to amplify the receiving volume in the handset and headset.*

## EXTRA HANDSET

Useful for involving a second person in your conversation, for talking or just listening.

## TAPE RECORDER

When a recording of the telephone conversation is needed, for evidence purposes, a tape recorder can be connected.

### HEADSET

The following headset functions are available.

*Note: To use the headset functions your telephone has to be equipped with option unit DBY 410 02. How to install the option unit, see separate installation instructions provided with the option unit.*

#### Activate/Deactivate the headset

Headset 

**Press the headset key to activate/deactivate the headset (pre-programmed)**

See section "Description". All calls can be handled via the headset.

#### Answer calls

Line 

**Press the flashing line key to answer**



**Press to terminate a headset call**

#### Make calls



**Dial the number**



**Press to terminate the call**

#### Headset to handset



**Lift the handset**

#### Handset to headset

Headset 

**Press the headset key (pre-programmed)**

**CONFERENCE UNIT**

For conferences with many participants, the conference unit enhances the speech quality. It provides full duplex and high quality conversation possibilities.

---

**ALARM  
INTERFACE UNIT**

This plug-in module is fitted into the bottom of the telephone. It makes it possible to transfer alarm signals from various devices via the telephone to the exchange and to a pre-defined extension. A special circuit layout provides maximum functional security.

To a telephone fitted with an alarm interface unit you can connect devices such as bathroom alarms for hotel rooms, emergency alarms for hospitals, bank security alarms and supervision of machines.

## PROGRAMMING GENERAL

If you require frequent use of certain facilities, you may program them on the programmable keys on the telephone. When you want to use the function, just press the key.

*Note: Programming of dial-by-name keys and individual abbreviated numbers are described in section "Abbreviated numbers" and how to program a new diversion address is described in section "Call forwarding".*

## PROGRAM A FUNCTION KEY

How to program a function on a programmable key:



**Enter programming mode**



**Press the desired programmable key**



**Select function code**

See section "Function codes and required data".



**Press the programmable key again**



**Enter associated number**

See section "Function codes and required data".



**Press the programmable key again**

**Continue with section "select ringing character"**

**or**



**Press to finish programming**

After approximately 10 seconds, the function key is active.



## Select ringing character



### Select ringing character (0-4)

See section "Function codes and required data".



### Press the programmable key again



### Press to finish programming

After approximately 10 seconds, the function key is active.

Example :



### Enter programming mode



### Press the desired programmable key



### Select function code



### Press the programmable key again



### Enter extension number



### Press the programmable key again



### Press



### Press the programmable key again



### Press to finish programming

## FUNCTION CODES AND REQUIRED DATA

Function	Function code	Associated number	Ringling character
Dial-by-name	10	Extension number	—
Post dialling	11	4 Call waiting	—
		5 Automatic callback	—
		6 Individual call pick up	—
		7 Radio paging	—
		8 Intrusion	—
* External line	12	The directory number of the line	0–4
Supervision	13	Extension number	0–4
Intercom line	14	Extension number	0–4
* Loudspeaker	15	The number of the group (0–7)	—
paging			
Common mailbox	18	Common mailbox number	—
Supervision slave	19	—	0–4
* R key	25	—	—
Conference	27	—	—
* Account number	30	—	—
External voice	34	—	—
mail			
Hold	35	—	—
Transfer	36	—	—
Save/Redial	37	—	—
Log on/off slave	43	—	—

Ringling function:

0 =No ringling.

1 =Ringling.

2 =Delayed ringling (after 10 seconds).

3 =One single ringling signal. (The signal is muted).

4 =One delayed ringling signal (after 10 seconds. The signal is muted).

\* Function needs to be programmed by system administrator.

*Note: Special authorisation is required when programming function-keys.*

## VISIBLE SIGNALS GENERAL

The key lamps on your telephone indicates with different signals the traffic state of the ongoing call or function.

## LAMP INDICATIONS



Extinguished lamp

The function is not active.



Steady light

The function is active.



Slowly flashing lamp

The line (or function) is put on hold.



Rapidly flashing lamp

An incoming call or message waiting.



Light with short breaks

Ongoing call.

### AUDIBLE ADJUSTMENTS GENERAL

In order to satisfy your personal needs, the BusinessPhone 250 /50 BusinessPhone system is equipped with many options to set and adjust a personal volume and ringing signal.

### HANDSET AND LOUDSPEAKER VOLUME

Use the volume keys. You can set different volume levels for internal and external calls and for background music. During a call, adjust handset listening volume in handset mode. Adjust loudspeaker volume in monitor mode or during background music.



**Press to change the volume**

### RINGING SIGNAL



By programming, you can adjust ringing type (2 types), ringing volume (10 steps) and ringing character (10 characters).

#### **Enter programming mode**

Now you can select ringing type, volume or character.

#### **Ringing type**

Select type 1 if you want the set ringing volume at a constant level, select type 2 if you want gradually increasing volume when the phone rings.



**Press**

**or**



**Press**

You will hear the selected type.



**Press to finish the procedure**

*Note: When type 2 is selected, the programming of the ringing volume is not applicable.*

## Ringing volume

② \* 0 — 9

### Press

You will hear the selected volume (0...lowest volume, 9...highest). You only have to press the last digit to select another ringing volume.



### Press to finish the procedure

*Note: This programming is not applicable when you have selected ringing type 2.*

## Ringing character

③ \* 0 — 9

### Press

You will hear the selected character. You only have to press the last digit to select another ringing character.



### Press to finish the procedure

## TONES AND SIGNALS

Tones are audible in the handset. Ringing signals are emitted from the phone. You can adjust the tones and signals on your phone. See section "Audible adjustments".

### Dial tone

(System ready to accept digits)



### Special dial tone

(System ready to accept digits, active diversion on telephone)



### Ringing tone

(Ringing signal to called party)



-repeated after 4 s

### Special ringing tone

(Ringing signal to line 2)



-repeated after 4 s

### Busy tone

(Called party is busy)



### Number unobtainable tone

(Called number not accessible or vacant)



### Blocking tone

(Call cannot be executed due to congestion or called party blocked)



### Verification tone

(Verification that ordered function is accessed)



### Intrusion tone

(Sent to all parties during intrusion)



### Conference tone

(Sent to all participants in a conference)



-repeated after 15 s

### Internal ringing signal



-repeated after 4 s

### External ringing signal



-repeated after 4 s

### Automatic call-back signal



*Note: The tones and ringing signals in this guide refer to the standard system but may vary between countries.*

## GLOSSARY

### ABBREVIATED NUMBER DIALLING

Initiating a call to a pre-programmed number by dialling a code or pressing a key. Short numbers can be: *1. Common, which means that all extensions can use them. 2. Individual, which means that they are programmed and used by each extension separately (10 numbers).* See section "Abbreviated numbers".

### ACCOUNT NUMBER

To place costs for external calls on a selected account number (up to 15 digits). See section "Other useful facilities".

### AUTOMATED ATTENDANT

A facility which sends voice instructions to internal and external callers, providing all options which can be chosen. Voice instructions lead the caller to the desired destination. See section "Other useful facilities".

### CALL-BACK

An indication to a busy extension, to inform the person that you want to speak to him/her. See sections "Internal messages" and "Outgoing calls".

### CAMP ON

To place (queue) a call to a busy extension. See section "Outgoing calls".

### COUNTER

The counter keeps track of the time and cost of your calls. See section "Call metering".

### DIAL-BY-NAME

Initiation of a call by operating a single key. Internal numbers (or common abbreviated numbers) can be stored on each extension. See section "Abbreviated numbers".

### DIRECTORY NUMBER

Numbers with 1-8 digits which are assigned to extensions or external lines or as common abbreviated numbers.

### DIRECT INWARD SYSTEM ACCESS (DISA)

If you are working externally, the DISA function enables you to make external calls (long distance) via the company PBX. You only pay for the call to your company. See section "Other useful facilities".

### DIVERSION

Incoming calls to an extension are diverted to another directory number (extension, common abbreviated number or the operator). There are three possibilities:  
*1. Direct, which means that all calls to an extension are forwarded directly.*  
*2. On no reply, which means that a call is forwarded if it is not answered within a certain time.*  
*3. On busy, which means that a call is forwarded if the extension is busy.*  
See section "Call forwarding".

### DIVERSION BYPASS

This is useful for letting urgent calls through to an extension where diversion is active. See section "Call forwarding".

### EXTENSION

All telephones connected to the PBX have a unique internal number (upto 3 digits).

### FUNCTION CODE

A two digit code that corresponds to a specific function. See section "Programming".

### HOLD

To park a call. See section "During calls".

### INFORMATION

Internal callers are informed about absence and time of return.  
External callers are diverted to the operator, where the same information is available. Information can be of two kinds: *1. Pre-programmed text information. 2. Voice information.*

### INTERCOM LINE

A two-way direct call function between two extensions, for instance an executive-secretary communication. See section "Other useful facilities".

### INTRUSION

To intrude on an ongoing call when a requested extension is busy. See section "Outgoing calls".


**(continued)**

## GLOSSARY (continued)


<b>ISDN</b>	Integrated Services Digital Network. Provides your system with supplementary services from the public net.
<b>LEAST COST ROUTING</b>	A function that automatically selects the cheapest way to connect your external call (not necessarily the shortest distance). See section "Least cost routing".
<b>LOUDSPEAKER PAGING</b>	All members of an extension group are "paged", i.e. receive a short, sharp tone on the loudspeaker followed by a voice message from the sender. See section "Group facilities".
<b>MAILBOX</b>	The mailbox system controls the messages that are left for or sent by you when you are absent. See section "Mailbox system".
<b>MESSAGE</b>	A message can be sent to any extension. This is useful when you receive the busy tone or get no answer. There are two kinds of message: 1. <i>"Call me" message</i> . 2. <i>Voice message</i> . See section "Internal messages".
<b>MUTE</b>	To switch the microphone temporarily off. See section "During calls".
<b>NIGHT SWITCHING</b>	Used for directing all incoming calls to one extension (answering position), for example when the office is closed. See section "Other useful facilities".
<b>PBX</b>	Public Branch Exchange. Your telephone switching system (e.g. BusinessPhone 250).
<b>PERSONAL CODE</b>	A four-digit code needed to e.g. block your extension and retrieve messages from the mailbox system. You can set your own personal code. See section "Security".
<b>PRE-DEFINED TEXT</b>	Pre-programmed absent information. See section "Information".
<b>THIRD PARTY</b>	A third connection (person), which can be included in an ongoing two person conversation. The connection can be internal or external. See section "During calls".
<b>TIE LINE</b>	An external line from the private network.
<b>TRANSFER</b>	During an internal or external ongoing call you can make an inquiry and then transfer the call to another party (internal or external). See section "During calls" and "Useful hints".
<b>TRUNK LINE</b>	A trunk line is the same as an external line. Can be either digital or analogue.



## INSTALL STAND




## INSTALL CABLES



- 1 Cable to handset
- 2 Cable to exchange
- 3 Space for personal number directory (optional)
- 4 Wallmounting screw holes

Wall  
mounting  
handset hook



You can put the cable to the handset in any of the two notches underneath the telephone. The cable to the exchange has to be plugged in "LINE".


## Change cables

To remove a cable, push down the plug's stop. Use a screw-driver to unlock the stop.

### PLACING THE TELEPHONE

- Do not place your telephone on sensitive surfaces. Use a non-slippery pad to protect your furniture from possible damage.
  - Do not place your telephone near sources of extreme heat, e.g. near the radiator.
  - Make sure that the line cable isn't creased.
- 

### ADJUST TELEPHONE



### CLEANING THE TELEPHONE

Use a slightly moistened (not wet) cleaning-rag or an anti-static rag and wipe off the telephone carefully. Do not use rough rags, solvents or aggressive cleaning fluids. Any damages of the telephone, that are caused by non-observance of these instructions, are not part of the liability given by the manufacturer.

## CONNECTIONS BETWEEN EXTERNAL LINES

With your BusinessPhone PBX, you can establish an external call diversion or a conference with more than one external party or transfer an external call too another external destination (e.g. a mobile phone). These features are very useful for everyday business life.

*Note: When these features are used, your BusinessPhone will occupy at least two external lines.*

However, there may be disadvantages in connecting to several external lines. We would therefore like to draw your attention to the following:

- **Please do not transfer external calls to an external mailbox, to information systems or to external parties before they have answered**
- **Try to avoid diverting calls to third parties before they have answered**
- **Cancel your calls by pressing the "Clear"-key**

If the external parties are not persons (mailbox, automated information or attendant systems, etc.), connections on external lines can last a long time, which can be costly. Moreover, such calls may occupy two of your system's external lines. You can restrict connections between the external lines by re-programming your system.

Please ask your system administrator or contact our service center for more information.

	Page		Page
Abbreviated numbers.....	28	Fixed diversion.....	15
Absent information.....	18	Follow me.....	17
Account number.....	37	Function codes and required data.....	50
Adjust telephone.....	58	Glossary.....	55
Alarm interface unit.....	47	Group call pick up.....	34
Answer a second call.....	7	Group facilities.....	31
Answer calls.....	7	Group hunting.....	34
Answer paging calls.....	31	Group paging.....	31
Audible adjustments.....	52	Handset and loudspeaker volume.....	52
Automated attendant.....	41	Headset.....	46
Automatic call-back.....	9	Hold.....	13
Background music.....	38	Incoming calls.....	7
Block extension.....	42	Individual abbreviated numbers.....	29
Busy extension.....	9	Individual diversion.....	16
Bypass blocked extension.....	43	Individual hold.....	13
Bypass call forwarding.....	17	Individual mailbox system.....	24
Call forwarding.....	15	Information.....	18
Call me message.....	22	Inquiry.....	11
Call-back.....	9	Install cables.....	57
Camp-on.....	9	Install stand.....	57
Change cables.....	57	Intercom line.....	38
Cleaning the telephone.....	58	Internal calls.....	8
Common abbreviated numbers.....	28	Internal messages.....	22
Common bell.....	35	Intrusion.....	9
Common hold.....	14	Key system.....	32
Common mailbox system.....	26	Lamp indications.....	51
Conference.....	13	Last external number redial.....	8
Conference unit.....	47	Least Cost Routing.....	44
Description.....	5	Loudspeaker paging.....	31
Dial-by-name.....	28	Mailbox system.....	24
Direct Inward System Access (DISA).....	40	Make calls.....	8
Diversion.....	15	Messages.....	22
Doorlock.....	41	Monitoring.....	10
Doorphone.....	41	Music.....	38
During calls.....	10	Mute.....	10
Enter information.....	18	Night switching.....	38
Erase information.....	21	Opening of the doorlock.....	41
External calls.....	8	Option unit.....	45
Extra handset.....	45	Optional equipment.....	45

	Page		Page
Other useful facilities.....	36	Save information.....	21
Outgoing calls .....	8	Security.....	42
Paging group.....	31	Select personal code .....	42
Personal code .....	42	Send message .....	22
Personal greeting.....	27	Slave log .....	39
Placing the telephone.....	58	Supervision/telephone attendance.....	33
Portable telephone (slave telephone) .....	39	Tandem configuration .....	39
Pre-defined texts .....	19	Tape recorder.....	45
Program a function key.....	48	Tones and signals .....	54
Programming.....	48	Transfer.....	12
Receive message.....	23	Two telephones.....	39
Redial number .....	8	Un-block extension.....	42
Refer back.....	11	Useful hints .....	59
Reminder.....	36	Visible signals .....	51
Ringing character.....	53	Voice information .....	20
Ringing signal.....	52	Voice messages .....	22
Ringing type.....	52	Volume .....	52
Ringling volume .....	53	When you receive busy tone .....	9
Save external number.....	8		



# QUICK REFERENCE GUIDE

## ANSWER CALLS

Answer:



Answer on another extension:



## MAKE CALLS

Normal calls:



or



Common abbreviated number:



Dial by name:



Individual abbreviated number: \*



Last external number redial:




## YOU GET BUSY TONE OR NO ANSWER

Automatic call-back:



Camp on:



Intrusion:



## DURING CALLS

Monitoring:



Individual hold:



## INQUIRY

Ongoing conversation:



Back to first party:



## REFER BACK

Press flashing key to connect:




## CONFERENCE

Ongoing conversation:



## TRANSFER

Transfer a call:



## MESSAGES

"Call me":



Voice:



Play-back:



Re-record:



Send:



Receive messages:



## CALL FORWARDING

Fixed diversion:




Individual diversion:



Cancel diversion:




Follow me, re-direct from answering extension:



Cancel from ans. extension:



Bypass call forwarding:



## INFORMATION

Enter information (pre-text):



(Select "info code" from list below)

(Enter "completing info")



Erase information:



IMPORTANT NUMBERS

IMPORTANT NUMBERS

Number	Function
	Account number 1
	Account number 2
	Automated attendant
	Background music number
	Common bell
	Common mailbox number
	Direct inward system access (DISA)
	Doorphone
	External line number 1
	External line number 2
	Group call pick-up
	Individual mailbox number
	Least cost routing
	Password
	Tie line number 1
	Tie line number 2

POST DIALLING DIGITS

Number	Function
	Answer calls on another extension
	Automatic call-back
	Call waiting
	Camp-on
	Intrusion
	Radio paging

ABBREVIATED NUMBERS

Common Abbreviated Numbers


Individual Abbreviated numbers

* * 0	
* * 1	
* * 2	
* * 3	
* * 4	
* * 5	
* * 6	
* * 7	
* * 8	
* * 9	



## ANSWER CALLS

Answer:



Answer on another extension:



## MAKE CALLS

Normal calls:



or



Common abbreviated number:



Dial by name:



Individual abbreviated number:



(Abbreviated no. 0-9)

Last external number redial:




## YOU GET BUSY TONE OR NO ANSWER

Automatic call-back:



Camp on:



Intrusion:




## DURING CALLS

Monitoring:



Individual hold:



## INQUIRY

Ongoing conversation:




Back to first party:



## REFER BACK

Press flashing key to connect:



## CONFERENCE

Ongoing conversation:



## TRANSFER

Transfer a call:



## MESSAGES

"Call me":



Voice:



Play-back:



Re-record:



Send:



Receive messages:




## CALL FORWARDING

Fixed diversion:




Individual diversion:



Cancel diversion:




Follow me, re-direct from answering extension:



Cancel from ans. extension:



Bypass call forwarding:



## INFORMATION

Enter information (pre-text):



(Select "info code" from list below)

(Enter "completing info")



Erase information:



info code	completing info
Time of return	1. hour (00-23) minute (00-59)
Date of return	2. month (01-12) day (01-31)
Lunch	3. back at, hour minute
Meeting	4. back at, hour minute
Vacation	5. back, month day
Illness	6. back, month day

QUICK REFERENCE CARD

These cards are used for DISA and to check messages.

DISA and Message check:

Company number

DISA Number

Message system

Personal code

ERICSSON

DISA and Message check:

Company number

DISA Number

Message system

Personal code

ERICSSON

DISA and Message check:

Company number

DISA Number

Message system

Personal code

ERICSSON

DISA and Message check:

Company number

DISA Number

Message system

Personal code

ERICSSON

# QUICK REFERENCE CARD

## Special account numbers for business calls:

Project name	Account number
1	→
2	→
3	→
4	→

*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R2B

## Special account numbers for business calls:

Project name	Account number
1	→
2	→
3	→
4	→

*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R2B

## Special account numbers for business calls:

Project name	Account number
1	→
2	→
3	→
4	→

*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R2B

## Special account numbers for business calls:

Project name	Account number
1	→
2	→
3	→
4	→

*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R2B

*Communication is our business*

Ericsson is the leading provider in the new telecoms world, with communications solutions that combine telecom and datacom technologies with the freedom of mobility for the user. With more than 100,000 employees in 140 countries, Ericsson simplifies communications for its customers - network operators, service providers, enterprises and consumers - the world over.

Ericsson's Information on Demand Database can be addressed at:  
<http://www.ericsson.com>

**Austria**

Ericsson Austria AG  
BusinessGroup BusinessPhone  
Pottendorfer Strasse 25-27  
A-1121 Vienna, Austria  
Telephone: +43-1-81 100-0  
Telefax: +43-1-81 100-5437

**United Kingdom**

Ericsson Limited Business Systems,  
Midleton Gate,  
Guildford Business Park,  
Guildford,  
Telephone: +44-(0)1483-407297  
Telefax: +44-(0)1483-407299

**Australia**

Ericsson Australia Pty Ltd.  
Ericsson Business Systems  
126-142 Trenerry Crescent  
Abbotsford Vic 3067, Australia  
Telephone, sales: +61-13-1374  
Service: +61-1800-033-216  
Telefax: +61-9284-5776  
<http://www.ericsson.com.au/AU/>

EN/LZTBS 102 193 R2B  
© Ericsson Austria AG 01/1999